





● Ferret operator's position

- 8 PP-85/APA-17 Power Unit for AN/APA-17
- 9 AN/APR-7 Radar Search Receiver—1000 to 3000 Mc.
- 10 AN/APA-23 Tape Recorder (u/w Search Receivers)
- 11 Antenna Switching Assembly SA-23/AR
- 12 Spare Tuning Units for AN/APR-4
- 13 AN/ANQ-1 Wire Recorder (Audio)
- 14 AN/APA-11 Radar Pulse Analyzer

- 15 AN/APA-17 Indicator—Radar DF 25 to 1000 Mc.
- 16 Instrument & Switch Panel
- 17 AN/APA-10 Panoramic Adaptor
- 18 AN/APA-24 (Mod.) Indicator Radar DF
- 19 PP-32/AR Power Unit (u/w Search Receiver)
- 20 AN/APR-5 Radar Search Receiver 1000 to 6000 Mc.
- 21 AN/APR-4 Radar Search Receiver 400 to 4000 Mc.
- 22 AN/ARR-7 Radio Search Receiver 550 Kc to 28 Mc.
- 23 AN/ARR-5 Radio Search Receiver 28 to 143 Mc.
- 24 Interphone Jack Boxes
- 25 AN/APA-24 (Mod.) DF Radar 85 to 450 Mc.
- 26 Special Interphone Amplifiers



● Navigator's position

- 27 Fluxgate Compass Indicator
- 28 SCR-717C Indicator
- 29 Instrument Panel
- 30 AN/APN-4 Indicator
- 31 AN/APN-4 Receiver
- 32 SCR-718 Altimeter Indicator
- 33 Interphone Jack Boxes
- 34 SCR-717C Radio Frequency Unit